INSTALLATION & REMOVAL INSTRUCTIONS FOR BIKON LOCKING ASSEMBLIES

Hub
Shaft
Shaft

ITEM

1: Inner ring 2: Outer ring 4: Front thrust collar


5: Socket head cap screws

3: Rear thrust collar

Locking Assemblies		Tight, Torque	Screw	Hex	Square	Pull
Metric Series 4000	Inch Series 4000-IN	MA ft-lb.	Size	Size (s) mm	Drive Size	Out Thread (d _B)
20x47 to 40x65	1 to 1½	11	M 6	5	1/4"	M 8
45x75 to 65x95	1 5/8 to 2 9/16	26	М 8	6	1/4"	M 10
70x110 to 95x135	2 3/4 to 3 3/4	51	M 10	8	36"	M 12
100x145 to 160x210	3 15/16 to 6	91	M 12	10	₩"	M 14
170x225 to 200x260	6 1/2 x 7 7/8	138	M 14	12	1/3"	M 16
220x285 to 260x325	270227227	214	M 16	14	14**	M 20
280x355 to 300x375		293	M 18	14	15"	M 22
320x405 to 340x425	******	420	M 20	17		M 24
360x455 to 420x515		565	M 22	17	34"	M 27
440x545 to 1000x1110		725	M 24	19	34"	M 30

*d_u pull out throad, provided only underneath cadmium plate screws of front thrust collar to facilitate Locking Assembly removal.

Hex Bit Socket





BIKON CORPORATION

West Mombasha Road RD-1 Box 660 Monroe, NY 10950

(914) 782-5650

METRIC SERIES 4000

INCH SERIES 4000-IN

The BIKON LOCKING ASSEMBLY is a keyless shaft-hub connector providing mechanically the same characteristics as a shrink fit. It is, nowever, easily adjustable and removable thus facilitating simple assembly and disassembly. Since torque is transmitted by friction between functional surfaces, condition of contact surfaces and proper tightening of the locking screws are of great importance.

IMPORTANT: To insure satisfactory performance and easy installation read first and then follow all instructions carefully.

INSTALLATION

Locking Assemblies are supplied ready for installation. However, used units — after thorough cleaning — should be lightly oiled, including bore, threads and screwhead contact area.

Do not use Molydebum-Disulfide, e.g., Molykote or Never-Seeze.

- Insert Locking Assembly into hub counterbore prior to shaft installation.
- After checking correct hub position, handlighten 3 or 4 equally spaced locking screws till initial contact is established.
- Tighten all locking screws in a diametrically opposite sequence. Initially use approximately 25% of specified tightening torque or even less on the first turns. Gradually increase tightening torque to MA as specified on subsequent tightening passes.

NOTE: To compensate for torque reduction due to setting of screws adjacent to a screw just being torqued, a tightening torque approximately 5% higher than specified is recommended for the final round.

 Reset torque wrench and make sure that no screw will turn any more at specified tightening torque MA:

NOTE: It is not necessary to check locking screwlightening torque again after operation of machinet

REMOVAL

 Loosen locking screws in several stages by using approx. ¼ turns, following a diametrically opposite sequence.

NOTE: Locking assemblies feature self releasing tapers. However, if for some reason thrust rings jam, a light tap on 3 equally spaced heads of loosened screws will positively release connection.

 Although hub and Locking Assembly are normally removed together, removal of Locking Assembly only from deep counterbores is accomplished by inserting pull out screws in threads located under cadmium plated locking screws.

