
Air valve(5/2 way, 5/3 way)



4A100 Series




Symbol




Product feature

- 1. Structure in sliding column mode: good tightness and sensitive reaction.
- 2. Three position air valves have three kinds of central function for your choice.
- 3. Double air control valves have memory function.
- 4. Internal hole adopts special processing technology which has little attrition friction, low start pressure and long service life.
- 5. No need to add oil for lubrication.
- 6. Integrate with the manifold to save installation space.

Flow chart






■Specification

Model	4A110-M5 4A120-M5	4A130C-M5 4A130E-M5 4A130P-M5	4A110-06 4A120-06	4A130C-06 4A130E-06 4A130P-06				
Fluid		Air(to be filtered by 4	tered by 40 µ m filter element)					
Acting		Exterio	r control					
Port size ①	In=Ou	ut=M5	In=Ou	it=1/8"				
Orifice size	5.5mm ² (Cv=0.31)	5.0mm ² (Cv=0.28)	12.0mm ² (Cv=0.67)	9.0mm ² (Cv=0.50)				
Valve type	5 port 2 position	5 port 3 position	5 port 2 position	5 port 3 position				
Operating pressure		0.15~0.8MP	MPa(21~114psi)					
Proof pressure		1.5MPa(215psi)						
Temperature °C		-20	~70					
Material of body		Alumini	ım alloy					
Lubrication (2)		Not re	quired					
Max. frequency ③	5 cycle/sec	3 cycle/sec	5 cycle/sec	3 cycle/sec				
Weight (g)	4A110-M5:85 4A120-M5:140		4A110-06:85 4A120-06:140	165				

- 1 G thread and NPT thread are available.
- ② Once lubricated air is used, continue with same medium to optimise valve life span. Lubricants like ISO VG32 or equivalent are recommended.
- 3 The maximum actuation frequency of no-load state.

Ordering code




Please refer to 64 for manifold specification and the order way.




4A100 Series

4A100

Inner structure





4A120




No.	Item	No.	Item	No.	Item
1	Screw	7	Spool	13	Screw
2	Spring	8	Wear ring	14	Spring holder
3	Bottom cover	9	Piston	15	Return Spring
4	Bottom cover gasket	10	Pilot body	16	Spring holder
5	Body	11	O-ring	17	E Clip
6	O-ring	12	Screw	18	Side cover

Dimension








4A200 Series




Symbol




Product feature

- 1. Structure in sliding column mode: good tightness and sensitive reaction.
- 2. Three position air valves have three kinds of central function for your choice.
- 3. Double air control valves have memory function.
- 4. Internal hole adopts special processing technology which has little attrition friction, low start pressure and long service life.
- 5. No need to add oil for lubrication.
- 6. Integrate with the manifold to save installation space.

Flow chart






Specification

Model	4A210-06 4A23 4A220-06 4A23		4A210-08 4A220-08	4A230C-08 4A230E-08 4A230P-08	
Fluid		Air(to be filtered by	10 μ m filter element)		
Acting		Exterio	r control		
Port size ①	In=Out=Ex	haust=1/8"	In=Out=1/4"	Exhaust=1/8"	
Orifice size	14.0mm² (Cv=0.78)	12.0mm² (Cv=0.67)	16.0mm² (Cv=0.89)	12.0mm ² (Cv=0.67)	
Valve type	5 port 2 position	5 port 3 position	5 port 2 position	5 port 3 position	
Operating pressure		0.15~0.8MP).8MPa(21~114psi)		
Proof pressure		1.5MPa	(215psi)		
Temperature °C		-20	~70		
Material of body		Alumini	um alloy		
Lubrication ②		Not re	quired		
Max. frequency ③	5 cycle/sec	3 cycle/sec	5 cycle/sec	3 cycle/sec	
Weight (g)	ht (g) 4A210-06:185 4A220-06:285 365		4A210-08:185 4A220-08:285	365	

- ① G thread and NPT thread are available.
- ② Once lubricated air is used, continue with same medium to optimise valve life span. Lubricants like ISO VG32 or equivalent are recommended.
- 3 The maximum actuation frequency of no-load state.

Ordering code



Please refer to 64 for manifold specification and the order way.

Phys.


44000





4A200 Series

4A200

Inner structure










No.	Item	No.	Item	No.	Item
1	Screw	7	Spool	13	Screw
2	Spring	8	Wear ring	14	Spring holder
3	Bottom cover	9	Piston	15	Return Spring
4	Bottom cover gasket	10	Pilot body	16	Spring holder
5	Body	11	O-ring	17	E Clip
6	O-ring	12	Screw	18	Side cover

Dimension








4A300 Series




Symbol




Product feature

- 1. Structure in sliding column mode: good tightness and sensitive reaction.
- Three position air valves have three kinds of central function for your choice.
- 3. Double air control valves have memory function.
- 4. Internal hole adopts special processing technology which has little attrition friction, low start pressure and long service life.
- 5. No need to add oil for lubrication.
- ${\bf 6.\ Integrate\ with\ the\ manifold\ to\ save\ installation\ space.}$

Flow chart






Specification

Model	4A310-08 4A320-08	4A330C-08 4A330E-08 4A330P-08	4A310-10 4A320-10	4A330C-10 4A330E-10 4A330P-10		
Fluid		Air(to be filtered by	40 μ m filter element)			
Acting		Exterio	r control			
Port size ①	In=Out=Ex	haust=1/4"	In=Out=3/8"	Exhaust=1/4"		
Orifice size	25.0mm ² (Cv=1.40)	18.0mm ² (Cv=1.00)	30.0mm ² (Cv=1.68)	18.0mm ² (Cv=1.00)		
Valve type	5 port 2 position	5 port 3 position	5 port 2 position	5 port 3 position		
Operating pressure		0.15~0.8MP	0.15~0.8MPa(21~114psi)			
Proof pressure		1.5MPa	(215psi)			
Temperature °C		-20	~70			
Material of body		Alumin	um alloy			
Lubrication ②		Not re	quired			
Max. frequency ③	4 cycle/sec	3 cycle/sec	4 cycle/sec	3 cycle/sec		
Weight (g)	4A310-08:275 4A320-08:365	505	4A310-10:275 4A320-10:365	505		

- 1 G thread and NPT thread are available.
- ② Once lubricated air is used, continue with same medium to optimise valve life span. Lubricants like ISO VG32 or equivalent are recommended.
- 3 The maximum actuation frequency of no-load state.

Ordering code



Please refer to 64 for manifold specification and the order way.

The second


44200

AITTAL

4A300 Series

4A300

Inner structure





4A32 0


4A330C

No.	Item	No.	Item	No.	Item
1	Screw	7	Spool	13	Screw
2	Spring	8	Wear ring	14	Spring holder
3	Bottom cover	9	Piston	15	Return Spring
4	Bottom cover gasket	10	Pilot body	16	Spring holder
5	Body	11	O-ring	17	E Clip
6	O-ring	12	Screw	18	Side cover
	1 2 3 4 5	1 Screw 2 Spring 3 Bottom cover 4 Bottom cover gasket 5 Body	1 Screw 7 2 Spring 8 3 Bottom cover 9 4 Bottom cover gasket 10 5 Body 11	1 Screw 7 Spool 2 Spring 8 Wear ring 3 Bottom cover 9 Piston 4 Bottom cover gasket 10 Pilot body 5 Body 11 O-ring	1 Screw 7 Spool 13 2 Spring 8 Wear ring 14 3 Bottom cover 9 Piston 15 4 Bottom cover gasket 10 Pilot body 16 5 Body 11 O-ring 17

Dimension








4A400 Series








Product feature

- 1. Structure in sliding column mode: good tightness and sensitive reaction.
- 2. Three position air valves have three kinds of central function for your choice.
- 3. Double air control valves have memory function.
- 4. Internal hole adopts special processing technology which has little attrition friction, low start pressure and long service life.
- 5. No need to add oil for lubrication.
- 6. Integrate with the manifold to save installation space.

■ Flow chart




AITTAE

Specification

Model	4A410-15	4A420-15	4A430C-15	4A430E-15	4A430P-15	
Fluid		Air(to be fil	tered by 40 µ m fil	ter element)		
Acting		Exterior control				
Port size 1		ln:	In=Out=Exhaust=1/2")			
Orifice size	50.0mm ²	(Cv=2.79)	3)		
Valve type	5 port 2	position		5 port 3 position		
Operating pressure		0.15	0.15~0.8MPa(21~114psi)			
Proof pressure			1.5MPa(215psi)			
Temperature °C			-20~70			
Material of body			Aluminum alloy			
Lubrication 2	Not required					
Max. frequency ③	3 cycle/sec					
Weight (g)	555	685	735			

- 1 G thread and NPT thread are available.
- ② Once lubricated air is used, continue with same medium to optimise valve life span. Lubricants like ISO VG32 or equivalent are recommended.
- ③ The maximum actuation frequency of no-load state.

Ordering code




Please refer to 64 for manifold specification and the order way.




4A400 Series

4A400





4A420




No.	Item	No.	Item	No.	Item
1	Screw	7	Spool	13	Screw
2	Spring	8	Wear ring	14	Spring holder
3	Bottom cover	9	Piston	15	Return Spring
4	Bottom cover gasket	10	Pilot body	16	Spring holder
5	Body	11	O-ring	17	E Clip
6	O-ring	12	Screw	18	Side cover


Dimension









4A420







4A430

